PARD



User Manual
Australia & NZ

Multipurpose Thermal Imaging FT32/FT32-LRF

1.Introduction	0:
2.Precautions	0:
3.Package Contents	02
4.Description & Key Features	03
5.Specifications	04
6.Components & Controls	08
7.Installation	12
8.Operation Instruction 8.1	2:
Shortcut Mode	22
8.2 Menu Mode	26

Thank you for your continued support and choosing PARD FT32/FT32-LRF thermal front clip-on series. Please read this manual carefully before using the device for the first time. Please follow the instructions in this manual to avoid any damage caused by improper usage.

After reading, please keep this manual for the future reference.

This manual provides step-by-step instructions on how to use your thermal monocular and is intended for your reference only.

PARD reserves the right to amend this manual at any time without prior notice to individual users. For the most up-to-date information, we recommend visiting PARD's official website. PARD reserves the final interpretation right of this manual.

- Please remove the insulating tape on the battery before first use. It is recommended to use a fully charged lithium-ion battery with a rated voltage of 3.7V.
- Please turn off the device and remove the battery when it's not in use for more than 10 days, and store the device & battery in a dry and safe place.
- Do not look directly to avoid eye damage when in use.
- Be extra cautious and handle the device with care during use or transportation. It is recommended to use the original
 packaging during transportation.
- Do not use the device to focus directly on strong sources of light such as the sun or electric welding. The detector may
 be damaged and it will void the warranty.
- Avoid lens scratches and damage caused by oil or chemical contamination of the lens. Keep the lens cap on when not in use.
- The device should be placed in a cool, dry, and ventilated environment without strong electromagnetic fields, and the
 working environment temperature should not be lower than (-20°C/-4°F) or higher than (50°C/122°F).
- Do not disassemble the device without authorization. If you encounter any problems, please contact our after-sales

- team and report them on our official website. Failure to do so will render the warranty service null and void.
- Attention! All PARD night-vision and thermal imaging devices require a license to be exported outside the country.

Icon	Contents	Quantity
E 7	FT32/FT32 LRF Multipurpose Thermal Imaging	1
794/53	3.7V 18650 Rechargeable lithium-ion battery	1
0	Adapter	1
	Eyepiece	1
6	Gasket	4
E P)	Type-C cable	1
	Allen wrench	2
	Cloth bag	1
•	User's manual	1
S	Warranty card	1

DESCRIPTION & KEY FEATURES

The FT32/FT32-LRF is a compact, lightweight multifunctional thermal imaging device, which can be used as a handheld monocular, a weapon mounted thermal imaging scope or as a front clip-on to existing optical scopes. The 12µm, NETD ≤ 25mK thermal imaging sensor can detect subtle temperature differences, giving you higher image resolution and clarity. As a thermal scope or thermal imaging monocular, it is accompanied by specialized lenses. Moreover, it incorporates various functions including ballistic calculation, catering to both aiming and searching needs.

Key features

- Multipurpose for being a thermal clip-on, monocular or thermal imaging scope
- No need to zero (as a clip-on)
- Ultra-sensitive sensor LWIR
- 4 1000 m High-precision range finder
- Infrared Image Enhancement Algorithm (IREA)
- Compact body, compact design

- Quick conversion of optical scope to thermal imaging scope
- Ballistic calculation
- WiFi
- Recoil resistance recording
- IP67 weatherproof rating
- 18650 Lithium-Ion rechargeable battery

Model FT32		FT32-LRF	
Sensor			
Detector Resolution(pixel)	384*288	384*288	
Pixel Size(μm)	12*12	12*12	
NETD	≤25mK (0.025°C)	≤25mK (0.025°C)	
Frame Rate(Hz)	50	50	
Human Detection Distance(m)	1400	1400	
Vehicle Detection Distance(m)	2600	2600	
Optics			
Objective Lens(mm)	35	35	
Optical Magnification(x)	3.5	3.5	
Digital Zoom(x)	2/4/6/8	2/4/6/8	
Continuous Digital Zoom			
Field of View (horizontal)	7.5°	7.5°	

Model	FT32	FT32-LRF	
Field of View (vertical)	5.6°	5.6°	
Field of View (diagonal)	9.4°	9.4°	
Eye Relief(mm)	30	30	
Diopter Adjustment(D)	±5	±5	
Display			
Туре	OLED	OLED	
Reticle Style	6	6	
Resolution(pixel)	1440*1080	1440*1080	
Scene Mode	City/Rain/Forest	City/Rain/Forest	
Image Mode	WT-HOT/BK-HOT/EDGE/RD-HOT/IN-HOT/SKY	WT-HOT/BK-HOT/EDGE/RD-HOT/IN-HOT/SKY	
Photo / Video			
Photo Resolution(pixel)	2592*1944	2592*1944	
Photo Format .JPG		.JPG	
Video Resolution(pixel)	1024*768	1024*768	
Video Format .mp4		.mp4	

Storage(GB)	TF card (Max.128)	TF card (Max.128)	
Model	FT32	FT32-LRF	
Image Engine	PARD IREA	PARD IREA	
Main Function			
LRF Detection Range(m)	N/A	1000	
PIP	Yes	Yes	
Gyroscope	Yes	Yes	
Loop Recording	Yes	Yes	
E-compass	Yes	Yes	
Hot Track	Yes	Yes	
Shutter	Mechanical shutter	Mechanical shutter	
Microphone	Yes	Yes	
Firmware Upgrade Yes		Yes	
Power Supply			
Battery Type	Li-ion 18650*1	Li-ion 18650*1	
Output Voltage(V) 3.7		3.7	

Model FT32		FT32-LRF	
Operating Time(h)	≤5	≤5	
External Power Supply Type-C		Type-C	
Environmental Chara	cteristic		
Degree of Protection	IP67	IP67	
Operating Temp(°C/°F)	p(°C/°F) -20~-50 /-4~122 -20~-50 /-4~122		
Recoil Resistance(J) 6000		6000	
Material			
Housing	Aluminium alloy	Aluminium alloy	
Objective Lens(mm)	All-glass multi-coated lens	All-glass multi-coated lens	
Measurement			
Product Dimension With eyepiece 142*60*77 (L*W*H, mm) With adapter 154*79*82		With eyepiece 150*60*80 With adapter 165*79*84	
N.W/pcs (Without Battery, g)	With eyepiece 370 With adapter 480	With eyepiece 410 With adapter 520	



No.	Name
0	Power indicator
2	Button panel
3	Battery cap
4	Clip-on eyepiece
6	Picatinny rail
6	Rangefinder(LRF modulel)
0	Objective lens cap
8	Objective lens
9	TF card slot
0	Type-C charging port
•	Power/Sleep

FT32



No.	Name
0	Power indicator
2	Button panel
3	Battery cap
4	Clip-on eyepiece
6	Picatinny rail
6	Objective lens cap
0	Objective lens
8	TF card slot
9	Type-C charging port
0	Power/Sleep

1. Unboxing

Before using this device, please do the following:

- Open the box and remove the device.
- Oheck to ensure that the package contents listed above are all included in the box.
- 6 Check the device for any damage to the display, body, lens, buttons, etc.
- Make sure that the objective lens and eyepiece are clean & functioning properly.

Note: If any accessories are missing or damaged, please contact PARD after-sales service.

2. Battery Installation and Startup

The battery installation steps are as follows:


2.1 Unscrew the battery cap clockwise and pull out the battery.



2.2 Tear off the insulating tape on the positive terminal of the battery.



2.3 Insert the battery, ensure the positive (+) side goes in first and tighten the battery cap in a clockwise direction.






Note:

- Please use a single 18650 rechargeable lithium-ion battery rated 3.7V voltage.
- Please pay attention to align the buckle interface.
- 3 Do not put battery into fire.
- O Do not put device into water when the battery cap is open.
- 5 Do not disassemble the device without authorization.
- O not pierce the device with sharp objects.
- Battery should be kept out of reach of children, and the positive and negative terminals of the battery should be installed correctly.

3. Adaptor Installation

To ensure the best user experience, we highly recommend using our original adapter included in the product packaging, as shown in picture 1.

Notes: When this device is used as a front clip-on, it needs to be installed with an adapter to be used normally.




- Take out the thermal imaging device, one adapter, inserts and an Allen wrench out of the box.
- Before installing the adaptor, turn on the device to see the clear icons on screen.
- Wrap 1-2 layers of insulating tape on the eyepiece housing for protection.
- Oock and rotate the thermal imaging body into the adapter lens and adapter, and lower the adapter locking lever.
- Secording to the diameter of the light sight front end, select a single washer or a combination of multiple washers, put the socket on the light sight front, observe whether the display is in the center position from the light sight eyepiece, and adjust the level, press the adapter lock handle.

4. Mount Installation

To ensure the best user experience, we highly recommend using our original mount, as shown in Picture 2.

Note: When this device is used as a thermal rifle scope, accessories need to be purchased additionally.



Picture 2

- 1 Take out the thermal imaging device from the box, and the extra purchased mounting bracket and accessories: (mount tightening screws, Allen wrench (D4.0mm) and gaskets).
- Position the device upside down, place the end of the mount with two screws facing the objective lens direction, attach the flat side of the mount on the bottom of the device. Adjust the mount to your preferred position (Attention: the end of the mounting bracket facing the eyepiece cannot exceed the junction edge of the rubber eyecup and the focusing ring, Failure to follow this direction may result in eye damage during use).
- 3 Install 3 screws in the front, middle and rear positions.
- 4 Use the Allen wrench and tighten the screws clockwise.
- If there is any horizontal deviation, you may use the two shims to adjust. Select the appropriate shim size and place it in the corresponding screw position, then repeat the above steps.


5. Diopter Focusing

This device only needs diopter focusing when it is used as thermal imaging scope or handheld monocular.

Diopter focusing is aimed to enable users with different visions to clearly see the content displaying on the screen, as depicted in Picture 3.

- 1 After powering the device, rotate the diopter focusing wheel so that you can see the screen clearly.
- 2 As long as you can clearly see the crosshair and text on the display, the diopter focusing setting has been completed.

Please note: The image is not seen clearly after adjustment as the objective lens is not properly focused yet.




Picture 3

6. Objective Lens Focusing

1 Before you focus the objective lens, ensure that the diopter focusing has been completed.

2 Aim at the target you want to see, and turn the focus lever of the objective lens until you can see the target image, as shown in picture 4.




Picture 4

7. Compass Calibration

This device only needs to do compass calibration when it is used as thermal imaging scope or handheld monocular.

After the eyepiece is focused, please use the "figure 8 pattern method" to calibrate the compass --Users are required to tilt and move the device in a figure 8 motion until the compass is calibrated , as shown in the Picture 5.

Note: the system of this product will be automatically recognized by the eyepiece, if the device is used as gun sighting eyepieces, the screen menu will have icons such as compass; If it is used as a light sight piece, the icon is not displayed.



8. Zeroing (Reticle Adjustment)

Reticle Adjustment refers to aligning the reticle with the point of impact at a zeroing distance, so that the position of the aiming point at this specific distance corresponds with the point of impact of the bullet.

Note: This device only needs to be zeroing when it is used as thermal imaging scope or handheld monocular.


1 Set the target: Set the target at zeroing distance and ensure that the device can obtain a good image.

Enter to sub-menu option "Reticle Adjustment": In the home screen mode, press [Key 5] to enter the menu mode and press [Key 4] to move the cursor to the reticle adjustment setting option. Press [Key 2] to enter the sub-menu interface, as shown in the Picture 6.




Picture 6

O Profile setting: After entering the Reticle Adjustment setting page, press [Key 3]/[Key 4] in"RTZ" item switching from A-E to create a new zeroing profile or edit an existing one, as shown in the Picture 7.



Picture 7


Shoot: Fire a 1st shot aiming at the center of the target (A), ensuring that you can see a clear point of impact (B) on the screen after the shot has been taken, as shown in the Picture 8.



Picture 8

- 6 Adjust zero value: In the same page, press [Key 2] to the second item "X:0", press [Key 3] or [Key 4] to freeze the screen; Then, adjust the "X" and "Y" values with [Key 3]/[Key 4] and switch between them by [Key 2] until the reticle center (A) aligns with the impact point (B) on the display screen.
- Save and exit: Press [key 2] to the "Save" item, use [Key 3]/[Key 4] to set "Save: Y". After the setting is completed, press [Key 2] to save and exit. The actual point of impact is moved to the center point of the reticle. (The reticle is always at the center of the screen, which can maximize the use of the entire observation field.)

Operation Instruction



1. Shortcut Mode





Picture 10

	Single press	Press and hold	Double press
Key 1	Power/Sleep	Power on/off	-
Key 2	Confirm/Take a photo	Record video/Save video	
Key 3	Up/Enlarge	View files	Turn on/Off picture-in-picture
Key 4	Ranging / Ballistic calculation	Turn off WiFi	
Key 5	Menu/Back	Back	Switch scene modes
Key 6	Switch image mode		Shutter correction

Explanation:

Key 1

1. Single press:

Press [Key 1] to put device into sleep mode when the device is on. Press [Key 1] again to wake up device from sleep mode.

2. Press and hold:

Press and hold [Key 1] to turn on / off the device.

Key 2

1. Single press:

Home screen mode: press [Key 2] to take photo.

2. Press and hold:

Home screen mode: press and hold [Key 2] to record a video. Press and hold [Key 2] again to save the video and exit.

Key 3

1. Single press:

① Home screen mode: press [Key 3] to zoom in 2x/4x/6x/8x times.

② Menu mode: press [Key 3] to scroll up or adjust the relevant option settings.

2. Press and hold:

Home screen mode: press and hold [Key 3] to view video and picture files saved on the memory card:

- ① Press [Key 3]/[Key 4] to switch between files.
- ② Press [Key 2] to play/pause the saved videos.
- ③ When playing videos, press [Key 3]/[Key 4] to fast forward or rewind 2x/4x/6x/8x times, press and hold [Key 5] to exit play/pause mode.
- 4 Press the [Key 5] button to access the following settings;

1)Delete:	2)Protect:	3)Slide Show:
 Delete Current 	 Lock Current 	 2 seconds
Delete All	 Unlock Current 	 5 seconds
	 Lock All 	 8 seconds
	Unlock All	

• Press and hold the [Key 5] button to return the home screen.

3. Double press:

Home screen mode: double press [Key 3] to turn on/off the picture-in-picture function.

Kev 4

1. Single press:

- ① Home screen mode: press [Key 4] to start the LRF range detection function. The distance will be measured and displayed automatically.
- ② Menu mode: press [Key 4] to scroll down or adjust the relevant option settings.

2. Press and hold:

Home screen mode: press and hold [Key 4] to close WiFi.

Key 5

1. Single press:

- ① Home screen mode: press [Key 5] to open/close the menu interface.
- ② Menu mode: in menu mode press [Key 5] to go back to the home screen.

2. Press and hold:

Home screen mode: press and hold [Key 5] to switch between City/Forest/Rain scene modes.

Key 6

1. Single press:

Home screen mode: press [Key 6] to switch image modes: WT-HOT/BK-HOT/EDGE/RD-HOT/IN-HOT/SKY

2. Double press:

Home screen mode: double press [Key 6] to perform a shutter calibration action.

2. Menu Mode

Home screen mode: single press [Key 5] to enter the menu mode to set various function options (the shortcut key function is invalid at this time), as shown in Picture 11.

2.1. Image Setting

Users can adjust the image contrast, brightness, detail and mode under this setting.

- ① Press [Key 4] to move the cursor to the Image Setting option, press [Key 2] to enter the sub-menu.
- Press [Key 2] to switch between Contrast / Brightness / Detail/ Mode options, and press [Key 3]/[Key 4] to adjust
 the option value.
- ③ Press and hold [Key 2] to exit. Upon the next startup, the device will maintain the saved image settings.

Image default settings: contrast value is 105. Detail is 2, sharpness is 2 and the mode value is 0.







Picture 11

2.2 Ballistic Calculator

Through the ballistic algorithm, the relevant parameters affecting the bullet trajectory are calculated and then an auxiliary crosshair is indicated on the side, for accurate shooting, as shown in Picture 12.

- ① Press [Key 3]/[Key 4] to move the cursor to the Ballistic Calculator setting option, press [Key 2] to enter the submenu interface.
- ② Press the [Key 3]/[Key 4] to move the cursor to select the Parameters/On/Off the ballistic calculator sub-option, and then press the [Key 2] to save or enter.
- After entering the Ballistic Calculator Parameter settings, press the [Key 2]/[Key 5] to move up or down to select the
 parameters option you want to change, and press the [Key 3]/[Key 4] to adjust the value of the corresponding
 parameter.


Parameter Settings Guide:




Picture 12

- Ballistic Data: There are 5 sets of profiles (A-E) that can be saved.
- **Velocity:** It is the measurement of bullet travel speed after it is fired from your rifle, expressed in "meters per second" (m/s) or "feet per second" (f/s), which can be measured by using professional testing equipment.
- Bullet Wt: Refers to the weight of the bullet, expressed in "grams" (g) or "grains" (gr), which can be obtained from the specifications section of the purchased bullets.
- Bullet BC: Ballistic coefficient (BC) of a bullet is a measure of its ability to overcome air resistance in flight. Data can be obtained from the specifications of the purchased bullets.
- Altitude: Refers to the altitude of the location, expressed in "meters" (m) or "feet" (ft), which is one of the
 important indicators affecting air density in ballistic calculations and can be measured by using professional testing
 equipment.

- Temperature: Refers to the local temperature, expressed in "Celsius" ("C) or "Fahrenheit" ("F), which is also one of
 the important indicators affecting air density in ballistic calculations, and can be measured by using professional
 testing equipment.
- Scope Ht: Refers to the height difference between the optical axis of the sight and the barrel, expressed in "millimeters" (mm) or "inches" (inch), which can be measured by professional testing equipment.
- Zero range: Refers to the unit distance expressed in "meter" (m) or "yard" (yds), usually set to 100m or 100yds, users can adjust according to their own preferences.
- Reference Point Shape and Color: Press [Key 3] to enter the option, press [Key 2] to switch between shape and color sub-options; press [Key3]/[Key4]] to select the desired shape and color. Three options of Shape and Color sub-options are available, press [Key 5] to confirm and return to the previous page, as shown in Picture 13.
- After adjusting your preferred settings, long press [Key 2] to save and return to the home screen. Long press [Key
 5] to exit without saving.







Picture 13

3. Range Unit Selection

Users can switch between "meter" or "yard" and the range unit can be updated instantly to meet the user's preference.

- ① Press [Key 3]/[Key 4] to move the cursor to the range unit selection option, and press [Key 2] to enter the sub-menu.
- ② Press [Key 3]/[Key 4] to choose between "meter" or "yard", then press [Key 2] to save and return to the previous page.

4. Reticle Adjustment

Reticle adjustment refers to aligning the reticle with the point of impact at a common shooting distance, so that the position of the aiming point at this specific distance is the bullet hit point, to achieve shooting accuracy.

- ① Press [Key 3]/[Key 4] to move the cursor to the reticle adjustment setting option, press [Key 2] to enter the sub-menu interface.
- ② Press [Key 2] to switch sub-menu options, and press [Key 3]/[Key 4] to adjust the value of the corresponding item.
- RTZ represents the crosshair storage type (there are 5 profiles A-E).
- "X" and "Y" represents the coordinates of the cross line.
- Style corresponds to the crosshair type (6 types for selection).
- Color corresponds to the color of the cross line (red/white/yellow/green 4 colors for selection).
- Under the Save item, "Y" means to save, and "N" means not to save.
- ③ After selecting your preferred settings, long press [Key 2] to save and return to the home screen;

5. Gyroscope

Note: This funtion will only be displayed on the menu bar when it is used as thermal imaging scope or handheld monocular after installing the eyepiece.

Through this function, the orientation of the device can be measured, and the yaw and pitch angles of the device can be displayed and calibrated.

- ① Press [Key 3]/[Key 4] to move the cursor to the gyroscope setting option, and press [Key 2] to enter the submenu interface.
- ② Press [Key 3/ Key 4] to select "Display" or "Calibration", and then press [Key 2] to enter;
- $\begin{tabular}{ll} @ \label{table properties} & \begin{tabular}{ll} @ \begin{tabular}{ll} & \begin{tabular$
- 4] to select "Off" or "On", and press [Key 2] to save and return to the menu interface.
- @ "Calibration" means to enter the calibration state. Press [Key 2] to select the "Calibration" option, please place the device on a horizontal plane surface, it will perform automatic calibration. After calibration, it will automatically return to the home screen.

6. Scene

There are three built-in scene modes, "City", "Forest" and "Rain". Users can choose any of the available scenes to achieve the best image display effect.

- ① Press [Key 3]/[Key 4] to move the cursor to the scene option, press [Key 2] to enter the sub-menu.
- ② Press [Key 3]/[Key 4] to move the cursor to select "City", "Forest" or "Rain" mode. Press [Key2] to save and return to the previous page.

7. Picture in Picture (PIP)

The top center of the display can show a 2x magnified picture to improve aiming visibility.

- 1 Press [Key 3]/[Key 4] to move the cursor to the PIP setting option, and press [Key 2] to enter the sub-menu.
- 2) Press [Key 3]/[Key 4] to move the cursor to select "PIP OFF" or "PIP ON",
- 3 After selection, press [Key 2] to save and exit.

8. Shutter Correction

Auto Shutter: When the system detects that the temperature of the detector has changed beyond a certain limit, it will close the mechanical shutter for self-calibration operation. There will be a 1-2 second image pause during self-calibration

Shutterless: the system monitors the temperature by the detector and automatically compensates in real time according to temperature changes. The mechanical shutter is always open, and the image will not be paused.

- ① Press the [Key 3]/[Key 4] to move the cursor to the shutter calibration setting option, and press the [Key 2] to enter the sub-option interface.
- ② Press the [Key 3]/[Key 4] to move the cursor to select "Auto Shutter" or "Shutterless" shutter calibration.
- (3) Press [Key 2] to save and return to the previous page.

9. Hot Track

The device can detect and display the highest temperature point on the screen and automatically keep tracking this target heat source.

- ① Press [Key 3]/[Key 4] to move the cursor to the hot track option and press [Key 2] to enter the sub-menu.
- ② Press [Key 3]/[Key 4] to move the cursor to select "Off" or "On". Press [Key 2] to save and return to the previous page.

10. Self-activated Recording

Just turn on self-activated recording and as soon as the device detects recoil, it will automatically start recording at 20 seconds intervals. The 20-second video footage of the shooting moment will be saved in the TF card.

- ① Press [Key 3]/[Key 4] to move the cursor to the self-activated recording setting, and press [Key 2] to enter the sub-option interface.
- ② Press the [Key 3/Key 4] to move the cursor to select the option "Off", "On" and "Impact Sensitivity".
- 3 After selecting "Off" or "On", press [Key 2] to save and return to the previous page;
- ⓐ After selecting "Impact Sensitivity", press [Key 2] to enter the sub-menu of sensitivity level, press [Key 3]/[Key 4] to move the cursor to select "Low", "Medium" or "High" mode; Press [Key 2] to save and return to the previous page.

11. Auto Power Off

The auto power off function allows the device to automatically power off after being idle. This setting will still be enabled after the next startup.

- ① Press [Key 3]/[Key 4] to move the cursor to select the auto power off setting, and press [Key 2] to enter the sub-option interface.
- ② Press [Key 3]/[Key 4] to move the cursor to select "Off", "1 Min", "10 Min" or "30 Min" duration options. After selection, press [Key 2] to confirm and save, and return to the previous page.

Note: After selecting your preferred time duration, the device will sense the last point of operation before beginning the shutdown i.e., shutdown will not start immediately after imputing the time but will start after the device has been idle then it automatically triggers the shutdown command.

12. Auto Recording

After auto recording is on, device will start recording and continue to record after the next startup.

- ① Press [Key 3]/[Key 4] to move the cursor to the auto recording setting option and press [Key 2] to enter the sub-menu.
- ② Press [Key 3]/[Key 4] to select "Off" or "On" options, press [Key 2] to save and return to the previous page.

13. Loop Recording

Through this function, users can customize the segmented recording duration or turn off the loop recording function. When the memory card capacity is full, the new recording will automatically overwrite the previous video file. When Off is selected, the loop recording feature is turned off.

— 34 -

- ① Press [Key 3]/[Key 4] to move the cursor to the loop recording option, and press [Key 2] to enter the sub-menu.
- ② Press [Key 3]/[Key 4] to move the cursor to select preferred loop time duration "Off", "1 Min" "3 Min" "5 Min"or "10 Min". Press [Key 2] to save and return to the previous page.

14. Date Stamp

Users can set whether to display the time stamp in the lower right corner of photos and videos taken.

- ① Press [Key 3]/[Key 4] to move the cursor to the date stamp option, press [Key 2] to enter the sub-menu;
- ② Press [Key 3]/[Key 4] to select On/Off date stamp, and press [Key 2] to confirm and exit.

15. Record Audio

User can set whether to record audio synchronously in the video.

- ① Press [Key 3]/[Key 4] to move the cursor to the recording audio setting option, press [Key 2] to enter the sub-menu.
- ② Press [Key 3]/[Key 4] to move the cursor to select "Off" or "On" option, after selection, press [Key 2] to save and return to the previous page.

16. WiFi

Through the WiFi connection, you can use your phone, PC or tablet as an external viewfinder enabling users to synchronously see the photos and videos on a larger screen.

- ① Press [Key 3]/[Key 4] to move the cursor to the WiFi setting option, and press [Key 2] to enter the sub-menu.
- ② Press [Key 3]/[Key 4] to move the cursor to select "On" or "Off" option. Select "Off", and press [Key 2] to confirm your selection and return to the previous page.

Steps to connect to your mobile device:

- Download "PardVision" from the Apple App Store or the Google Play Store.
- . Turn on the WiFi on your device and on your mobile device.
- Search the WiFi on your mobile device (the device WiFi network is a string of characters starting with PARD, which
 is a unique string of numbers). Please enter the password: 12345678 to connect.

Note: The menu interface cannot be opened after the WiFi function is turned on, please long press [Key 4] to turn off the WiFi and re-enter the menu interface.

17. Language

Users can choose their preferred language.

- ① Press [Key 3]/[Key 4] to move the cursor to the language setting option, press [Key 2] to enter the sub-menu.
- ② Press [Key 3]/[Key 4] to move the cursor to select the desired language. Press [Key 2] to switch the system language and return to the previous page.

18. Date/Time

Users can set the system date and time of the device.

- ① Press [Key 3]/[Key 4] to move the cursor to the date/time setting option, press [Key 2] to enter the sub-menu.
- ② Press [Key 3]/[Key 4] to adjust the setting date and time value, press [Key 2] to switch options, press [Key 5] to save and return to the previous page.

19. Format

If users want to reformat the TF Card, it will delete all the data on the TF card permanently. Data cannot be recovered after reformatting. Please operate with caution!

- ① Press [Key 3]/[Key 4] to move the cursor to the format option, press [Key 2] to enter the sub-menu.
- ② Press [Key 3]/[Key 4] to select Cancel / Ok, and press [Key 2] to confirm and exit the menu interface.

20. Blind Pixel Compensation

The blind pixel compensation algorithm enables automatic compensation for blind spots that no longer respond to light also reduces image distortion, as shown in Picture 14.

① Press [Key 3]/[Key 4] to move the cursor to the blind pixel compensation option, press [Key 2] to enter the sub-menu.

You will see an important reminder: please put on lens cap, long press the menu key to execute, short press the ranging key to exit.

② Put on lens cap, press and hold [Key 5] to start the blind pixel compensation. A prompt will display: "Blind spot compensation, please wait".

③ Once the compensation is completed, a prompt will appear: "Blind spot compensation back up". You can press [Key 3]/[Key 4] to move the cursor to backup: "Yes" or "No, and press [key2] to confirm your selection.



Picture 14

21. Default Setting

If users decide to reset the device, it will restore the device to the factory default settings and all of the user data and personalized settings will be deleted. Please operate with caution!

- ① Press [Key 3]/[Key 4] to move the cursor to restore default setting option, press [Key 2] to enter the sub-menu.
- ② Press [Key 3]/[Key 4] to move the cursor to select "Cancel" or "OK" option. After selection, press [Key 2] to confirm the relevant operation and return to the previous page.

22. Firmware Upgrade

System firmware can be updated to maintain an optimized current version.

Notes: Before upgrading operation, please insert the TF card with the upgrade software.

①Press [Key 3]/[Key 4] to move the cursor to the firmware upgrade option, and press [Key 2] to enter the sub-menu. You will see an important reminder: Upgrading firmware may cause damage to the equipment, please operate with caution!

② Press and hold [Key 5] to confirm and press [Key 2] to exit and return to the previous page.

Note: When performing this operation, please load the device with a fully charged battery and type-C power supply. Powering off the device during the firmware update process may cause damage to the device components. Please operate with caution.

23. Version

This function displays the device's firmware version.

- ① Press [Key 3]/[Key 4] to move the cursor to the version option, press [Key 2] to enter the sub-menu to view.
- ② Press [Key 2] again to exit and return to the previous page.